## **DBC-Mini**

## **Driver Body Worn Police Camera**

## **PC Encryption Software Instruction**

Step 1: Connect the device to the computer via USB cable, then turn on the device. Go back to step 1, double click the "Software" folder, choose the "Body camera background OS.exe", double click to enter it.

🏭 l 🕞 🚹 = l	US	B SOFTWARE		-	□ ×
File Home Share V	/iew				^ <b>?</b>
Copy Paste	Move Copy to Copy	New tem • Prop		Select all Select none	
		INCVV	u d Soor		0
Favorites	ame	Date modified	Туре	Size	2
🔲 Desktop	Driver	12/30/2014 7:51 PM	File folder		
Downloads	Software	12/30/2014 7:52 PM	File folder		
Image: A contraction process Image: This PC Image: Desktop Image: Documents Image: Documents Im	open it				
2 items 1 item selected					



0	Body camera background os			×
click it				
Connect Device		Login Device		
		Read Device ID		
		Set Device ID		
		Read Police ID		
		Set Police ID		
and the second se	Т	fime Synchronization		
Enter the password				
Enter the password again	a	Set Password		
		V Disk Mode		
0	Body camera background os			X
۲	Body camera background os			× I
Connect Device	Body camera background os	Login Device		×
Connect Device	Body camera background os	Login Device Read Device ID	_ □	×
Connect Device	Body camera background os	Login Device Read Device ID ice ID		×
Connect Device	Body camera background os	Login Device Read Device ID ice ID lice ID		×
Connect Device	Body camera background os	Login Device Read Device ID ice ID lice ID		×
Connect Device	Body camera background os	Login Device Read Device ID ice ID lice ID .ice ID ronization		X
Connect Device	Body camera background os	Login Device Read Device ID ice ID lice ID ice ID ronization		1 ×
Connect Device	Body camera background os	Login Device Read Device ID ice ID lice ID ice ID ronization		1 ×
Connect Device Connect Device the Enter the password again	Body camera background os	Login Device Read Device ID ice ID lice ID .ice ID ronization Set Password		1 ×
Connect Device Connect Device the Enter the password again	Body camera background os	Login Device Read Device ID ice ID lice ID ice ID ronization Set Password U Disk Mode		
Connect Device Connect Device the Enter the password again	Body camera background os	Login Device Read Device ID ice ID lice ID ice ID ronization Set Password U Disk Mode		

Step 2: Click the "Connect Device", the computer will remind you that "this device is connected", click "OK".

Step 3: Fill in the first blank with the original **password** "00000000" (eight zeros)

۲	Body camera background os		-		×
	enter 00000000	]			
Connect Device		Login Device	]		
THE OF REAL PROPERTY		Read Device ID	]		
		Set Device ID	]		
		Read Police ID	]		
		Set Police ID	]		
and all		Time Synchronization	]		
Enter the password					
Enter the password again		Set Password	]		
		V Disk Mode	1		
			1		
			_	_	_

Step 4:Click "Login Device", the computer will remind you that "The equipment login is successful ", click "OK".

0	Body camera background os		×
		click it	
Connect Device	******	Login Device	
		Read Device ID	
		Set Device ID	
		Read Police ID	
		Set Police ID	
and a		Time Synchronization	
Enter the password			
Enter the password agai	n	Set Password	
		V Disk Mode	
٥	Body camera background os	_ □	×
0	Body camera background os	_ □	×
© Connect Device	Body camera background os	_ 🗆	×
Connect Device	Body camera background os	_ □ Login Device Read Device ID	×
Connect Device	Body camera background os	Login Device Read Device ID	×
Connect Device	Body camera background os	Login Device Read Device ID ice ID lice ID	×
Connect Device	Body camera background os	Login Device Read Device ID ice ID lice ID ice ID	×
Connect Device The eq	Body camera background os	Login Device Read Device ID ice ID lice ID .ice ID	×
Connect Device The eq	Body camera background os	Login Device Read Device ID ice ID lice ID .ice ID ronization	×
Connect Device Connect Device The eq Enter the passed of	Body camera background os	Login Device Read Device ID ice ID lice ID .ice ID ronization	×
Connect Device Connect Device The eq Enter the password again	Body camera background os	Login Device Read Device ID ice ID lice ID .ice ID ronization Set Password	×
Connect Device Connect Device The eq Enter the password again	Body camera background os	Login Device Read Device ID ·ice ID lice ID .ice ID ronization Set Password U Disk Mode	×
Connect Device Connect Device The eq Enter the password again	Body camera background os	Login Device Read Device ID ice ID lice ID .ice ID ronization Set Password U Disk Mode	×

Step 5: Click "Read Device ID", the computer can read the device ID number. Click "OK".

0	Body camera background os		- 🗆 🗙
Connect Device	*****	Login Device	click it
		Read Device ID	
		Set Device ID	
		Read Police ID	
		Set Police ID	
and all		Time Synchronization	
Enter the password			
Enter the password again		Set Password	
		U Disk Mode	
٥	Body camera background os		- 🗆 🗙
Connect Device	*okokokokok	Login Device	
and the second	0000001	Read Device ID	
		ice ID	
The suc	ccess of ID reading device	lice ID	
	CII	CK IL .ice ID	
Allow at 2	ОК	ronization	
Enter t			
EILEF LIE DASSBULU			
Enter the password again		Set Password	
Enter the password again		Set Password	
Enter the password again		Set Password V Disk Mode	

Step 6:You can set the device ID number and the same way to manage the police ID, you can also set new password.

Bo	ody camera background os	- 0	×
Connect Device ** Connect Device **	******* Login Device O00001 enter the number Read Device ID Set Device ID Read Police ID Set Police ID Time Synchronization Set Password U Disk Mode		

0	Body camera backgrou	nd os 🛛 🗕 🗖 🗙
Connect Device	****	Login Device
The second se	0000001	Read Device ID <b>click it</b>
	123456	Set Device In
		Read Police ID
		Set Police ID
many a state		Time Synchronization
Enter the	password	
Enter the passw	ord again	Set Password
		U Disk Mode
0	Body camera backgrou	nd os 🗕 🗆 🗙
Connect Device	*****	Login Device
A TANK IF PATIENT	0000001	Read Device ID
		ice TD
	Setting the device ID succes	S lice TD
		aliale it
	ОК	
		ronration
Enter the	passnutu	
Enter the passw	ord again	Set Password
		V Disk Mode
	De du como de alconomi	
•	Body camera backgrou	na os 🗧 🗆 🧖
Connect Device		Login Device
	0000001	Kead Device ID
	123456	Set Device ID Click it
		Read Polic
		Set Police ID
and a		Time Synchronization
Enter the	password	
Enter the passw	ord again	Set Password
		V Disk Mode

0	Body camera background os		- 🗆 ×
Connect Device Connect Device Read the Enter the password again	******** 0000001  police officer ID success  click it OK	Login Device Read Device ID ice ID lice ID .ice ID ronization Set Password U Disk Mode	
0	Body camera background os		- 🗆 🗙
Connect Device	******** 0000001 123456 012345 123456 enter police ID	Login Device Read Device ID Set Device ID Read Police ID Set Police ID Time Synchronization Set Password U Disk Mode	
0	Body camera background os		- 🗆 🗙
Connect Device Connect Device Enter the password Enter the password again	********         0000001         123456         012345         123456	Login Device Read Device ID Set Device ID Read Police ID Set Police ID Time Synchronization Set Password U Disk Mode	click it

0	Body camera background o	os – 🗆 🗙
Connect Device Connect Device Set Enter the password	Body camera background o	Login Device Read Device ID ice ID lice ID ck it Set Password U Disk Mode
٢	Body camera background o	os – 🗆 🗙
Connect Device	*******         0000001         123456         012345         123456	Login Device Read Device ID Set Device ID Read Police ID Set Police ID Time Synchronization Set Password U Disk Mode
0	Body camera background o	os 🗕 🗆 🗙
Connect Device	*******  0000001  123456  012345  123456  *******  again *******	Login Device Read Device ID Set Device ID Read Police ID Set Police ID Time Synchronization V Disk Mode

٥	Body camera background	os – 🗆 🗙
Connect Device	******	Login Device Read Device ID
	Set the password successfully	tice ID lice ID lice ID ronization
Enter the p	assnut u	
Enter the passwo	ord again *******	Set Password
		V Disk Mode

Step 7:Click the "U Disk Mode", the device will enter the U disk mode, refer to following picture. Click "OK".

٥	Body camera background os			x
Connect Device	******** 0000001 123456 123456	Login Device Read Device ID Set Device ID Read Police ID Set Police ID	] ] ]	
Enter the password Enter the password again	******** ******* click it	Time Synchronization Set Password V Disk Mode	]	

٥	Body camera background	os	- 🗆 🗙
Connect Device	*******	Login Device Read Device ID	
Enter the	e U disk mode successfull OK	y lice ID lick it ronization	
Enter the passmonu	L1		
Enter the password again	*****	Set Password	
		V Disk Mode	

Step 8:After the device has entered the U disk mode, you will find there are two words on the device's screen "USB connect", and you can find there is a removable disk in "this PC" which means you can manage the data in the device. You can delete, upload, download, etc. Refer to this picture.



## American Bus Video Inc.

www.AmericanBusVideo.com (770) 263-8118 <u>sales@AmericanBusVideo.com</u> \*All DVR specifications, features, GUI, hardware subject to frequent change by the manufacturer without notice. All Rights Reserved. © American Bus Video Inc. 2015